INS CHECK POINTS

Stand	Latitude	Longitude	Max Wingspan	Max Length	Conditions	
50L*	53 25 49.26 N	006 14 07.70 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 50C VACANT
50C*	53 25 49.21 N	006 14 07.66 W	47.57m	54.43m	TOW ON, PUSH OUT.	STANDS 50L, 50R VACANT
50R*	53 25 49.61 N	006 14 10.01 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 50C VACANT
51L*	53 25 49.96 N	006 14 12.32 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 51C VACANT
51C*	53 25 49.45 N	006 14 11.98 W	65.00m	70.67m	TOW ON, PUSH OUT.	STANDS 51L, 51R VACANT
51R*	53 25 50.32 N	006 14 14.63 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 51C VACANT
52*	53 25 50.55 N	006 14 16.73 W	36.00m	44.51m	TAXI IN, PUSH OUT.	
53*	53 25 50.61 N	006 14 19.30 W	36.00m	39.48m	TAXI IN, PUSH OUT.	
105L*	53 25 52.26 N	006 14 35.12 W	27.05m	28.58m	TAXI IN, PUSH OUT.	
105R*	53 25 52.41 N	006 14 37.72 W	27.05m	28.58m	TAXI IN, PUSH OUT.	
106*	53 25 51.98 N	006 14 41.31 W	36.00m	44.51m	TAXI IN, PUSH OUT.	
107L*	53 25 50.70 N	006 14 44.54 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 107C VACANT
107C*	53 25 51.07 N	006 14 45.66 W	65.00m	73.86m	TAXI IN, PUSH OUT.	STANDS 107L, 107R VACANT
107R*	53 25 50.84 N	006 14 46.88 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 107C VACANT
108L*	53 25 51.05 N	006 14 49.21 W	36.00m	47.00m	Taxi in, push out.	Stand 108C vacant
108C*	53 25 51.15 N	006 14 50.29 W	65.00m	75.40m	Taxi in, push out.	Stands 108R, 108L vacant
108R*	53 25 51.18 N	006 14 51.55 W	36.00m	47.00m	Taxi in, push out.	Stand 108C vacant
109L*	53 25 51.31 N	006 14 53.90 W	36.00m	47.00m	Taxi in, push out.	Stand 109C vacant
109C*	53 25 51.41 N	006 14 54.95 W	65.00m	75.40m	Taxi in, push out.	Stands 109R, 109L vacant
109R*	53 25 51.44 N	006 14 56.25 W	36.00m	47.00m	Taxi in, push out.	Stand 109C vacant
110L*	53 25 51.57 N	006 14 58.59 W	36.00m	47.00m	Taxi in, push out.	Stand 110C vacant
110C*	53 25 51.65 N	006 14 59.41 W	65.00m	75.40m	Taxi in, push out.	Stands 110R, 110L vacant
110R*	53 25 51.70 N	006 15 00.94 W	36.00m	47.00m	Taxi in, push out.	Stand 110C vacant
111L*	53 25 52.23 N	006 15 03.22 W	36.00m	47.00m	Taxi in, push out.	Stand 111C vacant
111C*	53 25 51.91 N	006 15 04.05 W	65.00m	75.40m	Taxi in, push out.	Stands 111R, 111L vacant
111R*	53 25 52.35 N	006 15 05.57 W	36.00m	47.00m	Taxi in, push out.	Stand 111C vacant
118R*	53 25 54.16 N	006 15 09.91 W	36.00m	46.70m	TAXI IN, PUSH OUT.	
119L*	53 25 52.89 N	006 15 08.94 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STANDS 119C AND 119S VACANT
119C	53 25 52.32 N	006 15 07.71 W	64.75m	66.61m	TAXI IN, PUSH OUT.	STANDS 119L, 119S AND 119R VACANT
119S*	53 25 51.93 N	006 15 08.44 W	30.40m	30.50m	SELF MANOEUVRING.	STANDS 119L, 119C AND 119R VACANT
119R*	53 25 51.78 N	006 15 07.31 W	36.00m	52.30m	TAXI IN, PUSH OUT.	STANDS 119C AND 119S VACANT
120L*	53 25 50.20 N	006 15 07.50 W	36.00m	39.50m	TAXI IN, PUSH OUT.	STAND 120C vacant
120C*	53 25 49.99 N	006 15 06.01 W	64.75m	66.61m	TAXI IN, PUSH OUT.	STANDS 120L AND 120R VACANT
120R*	53 25 48.91 N	006 15 06.53 W	36.00m	39.50m	TAXI IN, PUSH OUT.	STAND 120C VACANT
121L*	53 25 48.94 N	006 15 04.86 W	36.00m	39.50m	TAXI IN, PUSH OUT.	
121*	53 25 48.95 N	006 15 02.60 W	36.00m	45.10m	TAXI IN, PUSH OUT.	
122*	53 25 48.82 N	006 15 00.26 W	36.00m	45.10m	TAXI IN, PUSH OUT.	
123*	53 25 48.69 N	006 14 57.91 W	36.00m	45.10m	TAXI IN, PUSH OUT.	
124*	53 25 48.56 N	006 14 55.56 W	36.00m	45.10m	TAXI IN, PUSH OUT.	
125*	53 25 48.43 N	006 14 53.22 W	36.00m	45.10m	TAXI IN, PUSH OUT.	
126*	53 25 48.30 N	006 14 50.87 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 200T VACANT AT ENTRY/EXIT
127*	53 25 48.17 N	006 14 48.53 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 200T VACANT AT ENTRY/EXIT
130*	53 25 44.38 N	006 15 01.15 W	35.80m	39.50m	TAXI IN, PUSH OUT.	
131S*	53 25 44.48 N	006 14 58.99 W	27.05m	27.20m	SELF MANOEUVRING.	
132R*	53 25 43.86 N	006 15 02.38 W	35.80m	44.51m	TAXI IN, PUSH OUT.	Stand 132C vacant
132C*	53 25 43.62 N	006 15 02.49 W	47.60m	54.10m	TAXI IN, PUSH OUT.	stands 132l, 132r vacant
132L*	53 25 44.13 N	006 15 03.56 W	35.80m	39.50m	TAXI IN, PUSH OUT.	stands 132c, 133c vacant
133L*	53 25 45.42 N	006 15 04.49 W	35.80m	39.50m	TAXI IN, PUSH OUT.	stand 133c vacant
133C*	53 25 44.60 N	006 15 03.47 W	47.60m	48.50m	TAXI IN, PUSH OUT.	stands 132l, 133l vacant
137A*	53 25 57.93 N	006 14 45.70 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 137T VACANT
137T*	53 25 57.86 N	006 14 42.98 W	64.00m	63.69m	TAXI IN, PUSH OUT.	STANDS 137A, 137B VACANT
137B*	53 25 57.80 N	006 14 43.35 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 137T VACANT
138L*	53 25 58.28 N	006 14 50.38 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 138T VACANT
138T*	53 25 58.10 N	006 14 48.33 W	50.90m	54.10m	TAXI IN, PUSH OUT.	STANDS 138L, 138R VACANT
138R*	53 25 58.15 N	006 14 48.03 W	36.00m	48.90m	TAXI IN, PUSH OUT.	STAND 138T VACANT
139L*	53 25 58.54 N	006 14 55.07 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 139T VACANT
139T*	53 25 58.37 N	006 14 53.03 W	50.90m	54.10m	TAXI IN, PUSH OUT.	STANDS 139L, 139R VACANT
139R*	53 25 58.41 N	006 14 52.73 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 139T VACANT
140L*	53 25 58.80 N	006 14 59.76 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 140T VACANT
140T*	53 25 58.62 N	006 14 57.72 W	50.90m	54.10m	TAXI IN, PUSH OUT.	STANDS 140L, 140R VACANT
140R*	53 25 58.67 N	006 14 57.42 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 140T VACANT
141L*	53 25 59.05 N	006 15 04.45 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 141T VACANT
141T*	53 25 58.88 N	006 15 02.41 W	50.90m	54.10m	TAXI IN, PUSH OUT.	STANDS 141L, 141R VACANT
141R*	53 25 58.92 N	006 15 02.11 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 141T VACANT
142L*	53 25 59.31 N	006 15 09.15 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 142T VACANT
142T*	53 25 59.14 N	006 15 07.10 W	50.90m	54.10m	TAXI IN, PUSH OUT.	STANDS 142L, 142R VACANT
142R*	53 25 59.18 N	006 15 06.80 W	36.00m	47.45m	TAXI IN, PUSH OUT.	STAND 142T VACANT
144L*	53 25 58.66 N	006 15 14.83 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 144C VACANT
144C*	53 25 59.57 N	006 15 14.48 W	65.00m	74.00m	TAXI IN, PUSH OUT.	STANDS 144L, 144R VACANT
144R*	53 25 59.22 N	006 15 12.59 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 144C VACANT
145*	53 25 58.18 N	006 15 16.73 W	41.10m	47.40m	TAXI IN, PUSH OUT.	
200L*	53 25 43.76 N	006 14 50.26 W	27.80m	29.95m	TAXI IN, PUSH OUT.	STAND 200C VACANT. STAND 200T VACANT AT ENTRY/EXIT
200C*	53 25 43.53 N	006 14 51.45 W	36.00m	39.50m	TAXI IN, PUSH OUT.	STANDS 200L, 200R VACANT. STAND 200T VACANT AT ENTRY/EXIT
200R*	53 25 43.86 N	006 14 52.15 W	27.80m	29.95m	TAXI IN, PUSH OUT.	STAND 200C VACANT
200T*	53 25 45.68 N	006 14 48.65 W	35.80m	39.50m	TOW ON, PUSH OUT.	
201*	53 25 42.85 N	006 14 52.92 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 201S VACANT
201S*	53 25 42.90 N	006 14 54.65 W	27.40m	27.17m	SELF MANOEUVRING.	STANDS 201 AND 202 VACANT
202*	53 25 41.90 N	006 14 54.64 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STANDS 201S AND 202S VACANT
202S*	53 25 41.70 N	006 14 56.80 W	27.40m	27.17m	SELF MANOEUVRING.	STANDS 202, 203L AND 203C VACANT
203L*	53 25 41.29 N	006 14 56.33 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STANDS 202S AND 203C VACANT
203C*	53 25 40.79 N	006 14 55.28 W	60.30m	63.70m	TAXI IN, PUSH OUT.	STANDS 202S, 203L AND 203R VACANT
203R*	53 25 40.38 N	006 14 55.92 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STANDS 203C VACANT
205T*	53 25 39.30 N	006 14 53.55 W	60.30m	63.70m	TAXI IN, PUSH OUT.	STANDS 205L AND 205R VACANT
205L*	53 25 39.55 N	006 14 55.08 W	36.00m	44.51m	TAXI IN, PUSH OUT.	STAND 205T VACANT
205R*	53 25 39.49 N	006 14 53.40 W	35.80m	39.50m	TAXI IN, PUSH OUT.	STAND 205T VACANT
206T*	53 25 40.08 N	006 14 50.64 W	34.10m	37.60m	TAXI IN, PUSH OUT.	
207T*	53 25 40.75 N	006 14 49.19 W	35.80m	44.51m	TAXI IN, PUSH OUT.	
311L*	53 25 36.51 N	006 14 44.26 W	34.10m	37.60m	TAXI IN, PUSH OUT.	STAND 311C VACANT
311C*	53 25 36.03 N	006 14 46.56 W	41.10m	47.40m	TAXI IN, PUSH OUT.	STANDS 311L, 311R VACANT
311R*	53 25 35.83 N	006 14 46.64 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 311C VACANT
312*	53 25 35.49 N	006 14 48.80 W	41.10m	47.40m	TAXI IN, PUSH OUT.	
313L*	53 25 35.07 N	006 14 50.73 W	36.00m	39.50m	TAXI IN, PUSH OUT.	STAND 313C VACANT
313C*	53 25 34.46 N	006 14 48.57 W	65.00m	74.00m	TAXI IN, PUSH OUT.	STANDS 313L, 313R VACANT
313R*	53 25 34.20 N	006 14 50.02 W	34.10m	44.51m	TAXI IN, PUSH OUT.	STAND 313C VACANT
314*	53 25 32.68 N	006 14 47.57 W	64.80m	66.90m	TAXI IN, PUSH OUT.	MAX WINGSPAN 47.60M WHEN STAND 315L OCCUPIED
315L*	53 25 31.18 N	006 14 47.91 W	34.10m	37.60m	TAXI IN, PUSH OUT.	STAND 315C VACANT. MAX SPAN 47.60M ON STAND 314
315C*	53 25 32.01 N	006 14 46.24 W	65.00m	74.00m	TAXI IN, PUSH OUT.	STANDS 315L, 315R VACANT
315R*	53 25 30.89 N	006 14 46.44 W	34.10m	44.51m	TAXI IN, PUSH OUT.	STAND 315C VACANT
316*	53 25 32.96 N	006 14 43.04 W	65.00m	74.00m	TAXI IN, PUSH OUT.	STANDS 317 AND 318L VACANT
317*	53 25 32.47 N	006 14 43.44 W	60.30m	63.70m	TAXI IN, PUSH OUT.	STAND 316 VACANT
318L	53 25 33.39 N	006 14 42.73 W	41.10m	47.40m	TAXI IN, PUSH OUT.	STANDS 316 AND 318C VACANT
318C*	53 25 34.94 N	006 14 41.71 W	64.80m	66.90m	TAXI IN, PUSH OUT.	STANDS 318L, 318R VACANT. STAND 400T VACANT AT ENTRY/EXIT
318R	53 25 34.78 N	006 14 41.55 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 318C VACANT. STAND 400T VACANT AT ENTRY/EXIT
400T*	53 25 31.79 N	006 14 36.49 W	34.20m	37.60m	PUSH IN, TOW OUT.	AIRCRAFT PARKED NOSE-OUT
400L*	53 25 30.50 N	006 14 32.55 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 400C VACANT. STAND 400T VACANT AT ENTRY/EXIT
400C*	53 25 29.36 N	006 14 32.87 W	65.00m	74.00m	TAXI IN, PUSH OUT.	STANDS 400L, 400R VACANT. STAND 400T VACANT AT ENTRY/EXIT
400R*	53 25 29.21 N	006 14 33.73 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 400C VACANT. STAND 400T VACANT AT ENTRY/EXIT
401L*	53 25 28.45 N	006 14 35.79 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 401C VACANT
401C*	53 25 27.36 N	006 14 36.24 W	65.00m	63.80m	TAXI IN, PUSH OUT.	STANDS 401L, 401R VACANT
401R*	53 25 27.23 N	006 14 37.08 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 401C VACANT
402L*	53 25 26.50 N	006 14 39.17 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 402C VACANT
402C*	53 25 25.39 N	006 14 39.56 W	65.00m	74.00m	TAXI IN, PUSH OUT.	STANDS 402L, 402R VACANT
402R*	53 25 25.26 N	006 14 40.43 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 402C VACANT
403L*	53 25 24.57 N	006 14 42.61 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 403C VACANT
403C*	53 25 23.42 N	006 14 42.91 W	65.00m	74.00m	TAXI IN, PUSH OUT.	STANDS 403L, 403R VACANT
403R*	53 25 23.28 N	006 14 43.78 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 403C VACANT
404L*	53 25 22.58 N	006 14 45.98 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 404C VACANT
404C*	53 25 21.38 N	006 14 46.55 W	65.00m	74.00m	TAXI IN, PUSH OUT.	STANDS 404L, 404R VACANT
404R*	53 25 21.28 N	006 14 47.01 W	35.60m	45.10m	TAXI IN, PUSH OUT.	STAND 404C VACANT
405T*	53 25 21.45 N	006 14 39.93 W	41.40m	47.40m	TAXI IN, PUSH OUT.	
406A*	53 25 21.76 N	006 14 37.23 W	41.40m	47.40m	TAXI IN, PUSH OUT.	STAND 406C VACANT
406C*	53 25 23.12 N	006 14 36.81 W	65.00m	75.40m	TAXI IN, PUSH OUT.	STANDS 406A, 406B VACANT
406B*	53 25 23.29 N	006 14 36.23 W	41.40m	47.40m	TAXI IN, PUSH OUT.	STAND 406C VACANT
407L*	53 25 23.91 N	006 14 33.82 W	34.10m	45.10m	TAXI IN, PUSH OUT.	STAND 407C VACANT
407C*	53 25 25.10 N	006 14 33.46 W	65.00m	75.40m	TAXI IN, PUSH OUT.	STANDS 407L, 407R VACANT
407R*	53 25 25.27 N	006 14 32.76 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 407C VACANT
408L*	53 25 25.89 N	006 14 30.47 W	36.00m	45.10m	TAXI IN, PUSH OUT.	STAND 408C VACANT
408C*	53 25 27.07 N	006 14 30.11 W	65.00m	75.40m	TAXI IN, PUSH OUT.	STANDS 408L, 408R VACANT
408R*	53 25 27.25 N	006 14 29.41 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 408C VACANT
409L*	53 25 27.82 N	006 14 27.06 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 409C VACANT. STAND 410T VACANT AT ENTRY/EXIT
409C*	53 25 28.94 N	006 14 25.56 W	60.30m	68.30m	TAXI IN, PUSH OUT.	STANDS 409L, 409R, 410T VACANT. Use min power only. Tow on if a/c stops during entry.
409R*	53 25 28.81 N	006 14 25.38 W	36.00m	46.70m	TAXI IN, PUSH OUT.	STAND 409C VACANT. STAND 410T VACANT AT ENTRY/EXIT
410T*	53 25 27.26 N	006 14 23.28 W	34.20m	37.60m	TOW ON, PUSH OUT.	STAND 409C VACANT.
411L*	53 25 23.26 N	006 14 22.23 W	34.10m	44.51m	TAXI IN, PUSH OUT.	STANDS 411C, 411T VACANT
411C*	53 25 22.46 N	006 14 21.54 W	60.30m	63.70m	TAXI IN, PUSH OUT.	STANDS 411L, 411R, 411T VACANT
411R*	53 25 22.52 N	006 14 21.61 W	34.10m	37.60m	TAXI IN, PUSH OUT.	STAND 411C, 411T VACANT
411T*	53 25 23.59 N	006 14 22.84 W	60.30m	58.82m	TOW IN, PUSH OUT.	STANDS 411L, 411C, 411R VACANT
412*	53 25 21.84 N	006 14 20.05 W	34.10m	37.60m	TAXI IN, PUSH OUT.	
413*	53 25 21.23 N	006 14 18.04 W	34.10m	37.60m	TAXI IN, PUSH OUT.	
414*	53 25 20.61 N	006 14 16.03 W	34.10m	37.60m	TAXI IN, PUSH OUT.	
415*	53 25 19.92 N	006 14 14.04 W	36.00m	44.51m	TAXI IN, PUSH OUT.	
416*	53 25 19.10 N	006 14 12.10 W	36.00m	44.51m	TAXI IN, PUSH OUT.	
417*	53 25 18.37 N	006 14 09.98 W	36.00m	37.60m	TAXI IN, PUSH OUT.	
418*	53 25 16.96 N	006 14 07.02 W	36.00m	44.51m	TAXI IN, PUSH OUT.	
614R*	53 25 27.25 N	006 15 53.70 W	36.00m	50.00m	Taxi in, push out.	STAND 614C VACANT
614C*	53 25 27.17 N	006 15 52.01 W	63.50m	75.40m	Taxi in, push out.	STANDS 614R, 614L VACANT
614L*	53 25 27.12 N	006 15 51.35 W	36.00m	50.00m	Taxi in, push out.	STAND 614C VACANT
615R*	53 25 26.99 N	006 15 49.01 W	36.00m	50.00m	Taxi in, push out.	STAND 615C VACANT
615C*	53 25 26.94 N	006 15 47.83 W	63.50m	75.40m	Taxi in, push out.	STANDS 615R, 615L VACANT
615L*	53 25 26.87 N	006 15 46.66 W	36.00m	50.00m	Taxi in, push out.	STAND 615C VACANT
616R*	53 25 26.74 N	006 15 44.32 W	36.00m	50.00m	Taxi in, push out.	STAND 616C VACANT
616C*	53 25 26.68 N	006 15 43.14 W	63.50m	75.40m	Taxi in, push out.	STANDS 616R, 616L VACANT
616L*	53 25 26.61 N	006 15 41.97 W	36.00m	50.00m	Taxi in, push out.	STAND 616C VACANT
617R*	53 25 27.41 N	006 15 39.48 W	36.00m	50.00m	Taxi in, push out.	STAND 617C VACANT
617C*	53 25 27.12 N	006 15 39.73 W	60.30m	63.70m	Taxi in, push out.	STANDS 617R, 617L VACANT
617L*	53 25 27.51 N	006 15 37.71 W	36.00m	50.00m	Taxi in, push out.	STAND 617C VACANT
618R*	53 25 33.40 N	006 15 30.06 W	42.80m	54.50m	Taxi in, push out.	STAND 618C VACANT
618C*	53 25 33.42 N	006 15 32.23 W	64.80m	75.40m	Taxi in, push out.	STANDS 618R, 618L VACANT
618L*	53 25 33.16 N	006 15 33.03 W	36.00m	50.00m	Taxi in, push out.	STAND 618C VACANT
619R*	53 25 33.61 N	006 15 35.75 W	36.00m	50.00m	Taxi in, push out.	STAND 619C VACANT
619C*	53 25 33.68 N	006 15 36.92 W	64.80m	75.40m	Taxi in, push out.	STANDS 619R, 619L VACANT
619L*	53 25 32.99 N	006 15 38.21 W	36.00m	50.00m	Taxi in, push out.	STAND 619C VACANT
620R*	53 25 33.13 N	006 15 40.56 W	36.00m	50.00m	Taxi in, push out.	STAND 620C VACANT
620C*	53 25 33.94 N	006 15 41.62 W	64.80m	75.40m	Taxi in, push out.	STANDS 620R, 620L VACANT
620L*	53 25 33.26 N	006 15 42.90 W	36.00m	50.00m	Taxi in, push out.	STAND 620C VACANT
621R*	53 25 33.39 N	006 15 45.25 W	36.00m	50.00m	Taxi in, push out.	STAND 621C VACANT
621C*	53 25 34.28 N	006 15 45.91 W	64.80m	75.40m	Taxi in, push out.	STANDS 621R, 621L VACANT
621L*	53 25 33.89 N	006 15 47.53 W	36.00m	46.40m	Taxi in, push out.	STAND 621C VACANT

NOTE 1: * DATA WHOSE ACCURACY HAS NOT BEEN QUALITY ASSURED.

NOTE 2: STANDS HP1 AND HP2 ARE USED FOR ENGINE START-UP/SHUT DOWN ONLY.

NOTE 3: RESPONSIBILITY FOR CONTROL OF SURFACE TRAFFIC ON THE: - APRON - RESTS WITH THE AIRPORT AUTHORITY.

MANOEUVRING AREA - RESTS WITH THE AIR TRAFFIC SERVICES.

THE SERVICE PROVIDED BY ATC ON THE APRON IS ON AN INFORMATION ONLY BASIS.

NOTE 4: THE COORDINATES PROVIDED REPRESENT THE FRONT NOSE-IN POINT OF THE STAND.

NOTE 5: AIRCRAFT ARE PROHIBITED FROM ENTERING ANY STAND WITHOUT THE GUIDANCE OF A MARSHALLER, OR THE ADVANCED VISUAL DOCKING GUIDANCE SYSTEM (AVDGS) WHERE PROVIDED (SEE EIDW AD 2.9.1).

NOTE 6: REFER TO CURRENT AIP SUPPLEMENTS FOR DETAILS OF STANDS NOT SHOWN ON THIS CHART.